#### INSTALLATION INSTRUCTIONS

## N-MR-EU/EL

Electric Mortise Lock

# CAL-ROYAL PRODUCTS, INC. USA


#### INSTALLATION

- 1. For device or trim preparation, see their directions.
- 2.Prepare door for Mortise lock (see N-MR7700 & N-MR9800 mortise exit device instruction).
- 3.Install bridge rectifier when using 12 or 24 VAC/DC power supply.
- 4. Wire Mortise lock as shown. Leave adequate lengths of wire to make all connections before inserting lock in door.
- 5.**TEST OPERATION:** Applying power to the solenoid of fail secure lock unlocks the trim. Applying power to the solenoid of fail safe locks the trim.
- 6.Install mortise lock.

#### **LEGEND OF TERMS**

**EU:** (Fail Secure) When power is applied, the mortise lock will unlock. When power is removed, the mortise lock is locked. **EL:** (Fail Safe) When power is applied, the mortise lock will lock. When power is removed, the mortise lock is unlocked.

#### **SCHEMATIC DIAGRAM**



### **ELECTRICAL SPECIFICATIONS**

#### **SOLENOIDS:**

VOLTS CURRENT COIL RESISTANCE

12V~24VAC/DC 300mA 8.2 Ohms +/- 10%

**WIRE DIMENSIONS: 300V 22AWG** 

ELG-8021-07/23-1of1