



1. SURFACE OF DOOR WHERE EXIT DEVICE IS TO BE APPLIED MUST BE FLUSHED
2. SEE MASTER SHEET FOR AREAS REQUIRING REINFORCEMENTS
3. WE RECOMMEND THAT ALL TAPPED HOLES BE DRILLED AND TAPPED IN FIELD
4. TOLERANCE ON ALL DIMENSIONS $\pm 1/64"$



9800 PANIC RIM EXIT DEVICE

9800

VERSION DATE
APR-16
2012
CAL-ROYAL PRODUCTS INC