

INSTALLATION INSTRUCTIONS for
Cbco Carry Bar

1. Cbco Carry Bar may be supplied with Dorco Coordinator.
2. Locate hole as shown on Inactive Door. Drill $3/8"$ ϕ hole for Sex bolts.

