- 1. Dimensions of X and Y are dependent on the door thickness.
- 2. Strike is for use with 1''(25mm) throw deadbolt functions.
- 3. When using door silencers, strike location on frames must be adjusted to its thickness.

