

1. MARK DOOR

- A. Fold and apply to high edge of door bevel and mark center of door edge as indicated on template at the desired height from the floor.
- B. Mark center hole on door face through guide on template for 2-3/8" (60mm) or 2-3/4"(70mm) backset.

2. DRILL HOLES

- A. Drill thru door face as marked for lockset. It is recommended that holes be drilled from both sides to presvent splitting. Hole size is 2-1/8"(54mm) for standard installations.
- B. Drill 1"(25mm) hole in center of door edge thru 2-1/8"(54mm) hole for latch. CAUTION: Check center of latch hole for alignment with strike center on jamb to ensure free movement of latch bolt.

VERSION

ver. 1.0 rev. 01/12

BY: bteves/adg

UNIT

inches (mm)

	CAL-ROYAL PRODUCTS, INC.	6605 Flotilla St. City of Commerce CA 90040 USA Tel: (323) 888-6601 FAX: (323) 888-6699 Website: cal-royal.com Email: sales@cal-royal.com	ITEM NO.	DESCRIPTION	ANSI	SCALE
			PRE, RITZ, SIG - 05	ASHLEY SERIES RESIDENTIAL LOCKSET FUNCTION: STOREROOM	Grade 3	1:1
						PAGE 1 OF 1