

- 1. Determine where the wall bumper will be mounted, then mount the steel plate to the wall.
- 2. Secure the plate with screws using a philips screw driver. Use the plastic anchors if necessary.

## Note: The long leg of the plate should be at the top position.

- 3. Insert the rubber to the casing.
- 4. The long leg of the plate should fit into the groove of the casing. (see illustration above)
- 5. Use an allen wrench to secure wall bumper with the set screw at the bottom of the casing.

The illustration and technical description in this cut sheet is current as of the date in the version date on the right. Cal-Royal Product reserves the right to, and may, on occasions, make changes and/or improvements in designs and dimensions without prior notice.

**DESCRIPTION** 



1/2"

6605 Flotilla St. City of Commerce CA 90040 USA Tel: (323) 888-6601 FAX: (323) 888-6699 Website: cal-royal.com Email: sales@cal-royal.com

WBSQ-2

ITEM NO.

1 3/8"

SQUARE WALL MOUNT
SQUAINE WALL WOUNT
STOP/BUMPER

ANSI	SCALE
	NOT TO SCALE
	PAGE 1 OF 1

inches (mm) ver. 1.0 rev. 01/21

BY: CL/CT

UNIT

**VERSION**