


## HOW TO CONVERT TRACK441 FROM HOLD OPEN TO DOOR STOPPER.




1. Remove end cap.




2. Slide HOLDER/STOPPER and SLIDER out of the track.

3. Detach or disengage SLIDER from HOLDER/STOPPER.



4. Rotate both the HOLDER/STOPPER and SLIDER 180°.



5. Slide back the HOLDER/STOPPER and SLIDER to the track.

6. Open the door to desired opening, then lock HOLDER/STOPPER by turning the hex lock screw clockwise.

