





INSTALLATION INSTRUCTIONS & TEMPLATE

EU678 SERIES RIM EXIT DEVICE



NOTE: ALL DIMENSION IN MILLIMETER