


HOW TO USE


- Standard

1. Insert the core into the housing.
2. DO NOT USE 'PUSH BUTTON'
3. Insert the lever into the core.
4. Rotate the lever.



- Need more cutting

1. Insert the core into the housing.
2. PUSH THE 'PUSH BUTTON'
3. Insert the core MORE.
4. Insert the lever into the core.
5. Rotate the lever.



* CAUTION

1. Housings should be fixed by door locks or any other tools when cut a poll.
2. The lever should be in the core when storing.