




Installation Manual for SDH-PLTD



(x1)



(x4)

(x2)



11/64"x1 17/64"

ST4.2x32(x1)



9/64"x25/32"

ST3.5x20(x2)






11/64"x1 3/16"

ST4.2x30(x1)



13/64"x1 3/16"

ST5x30(x1)



11/64"x1 17/64"


ST4.2x32

11/64"x1 3/16"

ST4.2x30

ST5x30

13/64"x1 3/16"



ST3.5x20

9/64"x25/32"

Door

Wall