

RX7700 SWITCH KIT

INSTALLATION INSTRUCTIONS

The RX7700 is a Field Installable Request to Exit (SPDT) for Cal-Royal 7700 Series Door Exit Devices.



KIT INCLUSIONS

- A. New RX Switch w/ Mounting Bracket
- B. Label Sticker
- C. Cable Tie Mount
- D. Cable Tie

SPECIFICATIONS

SWITCH: RATED AT 0.5A @24V AC/DC
GREEN - COMMON (C)
BLUE - NORMAL OPEN (NO)
GRAY - NORMAL CLOSED (NC)

TOOLS REQUIRED


Philips Screw Driver




1. Remove Exit Device End Cap.



2. Slide and remove the shim from the body.



3. Remove the existing shim edge cover.



4. Replace shim edge cover with the RX-switch.
May feel some resistance on 1st installation.
(use a rubber mallet if needed)

RX7700 SWITCH KIT


INSTALLATION INSTRUCTIONS



5. Make sure RX-switch is firmly secured to the shim.



6. Flip the shim cover and attach the Label Sticker and Cable tie mount using its pre-installed double sided adhesive.




7. Secure the RX-switch wire using the Cable tie, for wire management.



8. Re-insert the shim by sliding it back in place to the Exit Device body. Then check the function of the RX-switch.



9. Re-install the End Cap of the Exit Device.



10. Fasten the (2) screws to the End Cap.